

Model 6200 • Timer Large Display Timer

Count Up or Count Down With Two Timers in One



The Model 6200 Timer System serves as a speaker or event timer by monitoring speakers or coordinating timed scheduled events, such as stage performances or radio and television broadcasts.

Microframe's Model 6200 Timer operates in either count up or countdown mode. The keypad that operates the system features an LCD display which allows the local display to view hours, minutes

and seconds. With two full-feature timers in one package, you can view both timers simultaneously. The timer can be programmed to automatically reset and reload or reset and start over. For instance, give the speaker a "two-minutes-to-start" countdown by programming the timer "B" to start when timer "A" stops.

Timer Keypad

The keypad's LCD display shows both "A" and "B" timers simultaneously and allows the user to select which timer will appear on the remote display. Changes entered on timer "A" does not affect the contents and/or mode of timer "B." Either timer can count up or down and start or stop independently. Timer "A" can start timer "B" or show the time of day.

Display Options

Series 6200 Timers are available in 4- and 6-digit versions. Most commonly used are the 4-digit displays showing hours/minutes or minutes/seconds, and the 6-digit displays showing hours/minutes/seconds. These displays feature 5.5" tall characters visible up to 125 feet, and they come in attractive extruded aluminum cases with a red Plexiglas front panel. These cases are anodized for scratch-resistant purposes. Included with the system is everything needed for complete installation. One cable from the timer supplies both power and signal to the display(s). Multiple displays can be added to enhance viewing.

- Motivational speaking
- Radio or television broadcasts
- Pre-recorded taped messages
 - Courtroom testimonies
 - Stage performances
- Event timer at theme parks

Product Pricing:

**Each Timer System includes one Display, one Model 6200 Keypad and Power Adapter, and 100 feet of connecting cable.



System 62104 Timer . . \$638

- One Model 6200 Keypad & Power Adapter
- One Model 940 Remote Display
- 100-ft (30m) Connecting Cable
- Extra Display \$279



System 62106 Timer . . \$718

- One Model 6200 Keypad & Power Adapter
- One Model 960 Remote Display
- 100-ft (30m) Connecting Cable
- Extra Display \$349



System 62112 Timer . . \$744

- One Model 6200 Keypad & Power Adapter
- One Model 9620 Remote Display
- 100-ft (30m) Connecting Cable
- Extra Display \$375



Mini-Display System.....Call for information

