

6200 Series Timer

APPLICATIONS

• The 6200 Timer system serves as a lecturer or event timer helping to coordinate timed and scheduled events, such as stage performances, audio and visual recording, radio and television broadcasts.

FEATURES

- Count up or count down with two timers in one
- Operates in either count up or count down mode
- View both timers simultaneously on the timer keypad
- Program timer keypad to automatically reset, reload and restart



6200 Keypad

TIMER KEYPAD

The Keypad's LCD display shows both "A" and "B" timers simultaneously and allows the user to select which timer will appear on the remote display. Changes entered on timer "A" do not affect the contents and/or mode of timer "B." Either timer can count up or down and start or stop independently. Timer "A" can start timer "B" or show the time of day.

The Keypad features a time-of-day clock button to display a clock when not using the timer function. The Timer Keypad's LCD screen provides optimum control by the operator by viewing the timer as it is being displayed on the LCD display that may be wired to the front of the room, another location or near the speaker.



62104 Timer System

DISPLAY OPTIONS

Series 6200 Timers are available in 4 and 6-digit versions. The 4-digit display shows hours/minutes or minutes/seconds, and the 6-digit display shows hours/minutes/seconds. These displays feature 5.5" tall characters visible up to 125 feet. They feature attractive extruded aluminum cases, anodized for scratch-resistant purposes with red LEDs. Included with the system is everything needed for complete installation. One cable from the timer supplies both power and signal to the display(s). Multiple displays can be added to enhance viewing.



**Model 941
Mini-Display**

MINI-DISPLAY

The Microframe Model 941 Mini-Display features 1-inch tall digits viewable from up to 30 feet and shows 4-digit numbers. The Model 941 is operated by the 6200 Timer Keypad or the Model 904 Keypad.

PRICING

62104 Timer System	\$638
One Model 6200 Keypad & Power Adapter	
One Model 940 4-digit Display	
100-ft (30m) Connecting Cable	
Extra Model 940 Display.....	\$269
Model 941 Mini-Display	\$199

62106 Timer System	\$718
One Model 6200 Keypad & Power Adapter	
One Model 960 6-digit Display	
100-ft (30m) Connecting Cable	
Extra Model 960 Display.....	\$349
6200 Timer Keypad	\$349

**Each Timer System includes one Display, one Model 6200 Keypad and Power Adapter, and 100 feet of connecting cable for screwdown connectors.

microframe®

5400 Series

Timer/Counter/Clock

SERIES 5400 TIMER/COUNTER/CLOCK

The 5400 is a Stand-Alone timer that maybe programmed to either display the time as a clock or as a count up or down timer. The display has large 5.5" tall numbers that are visible up to 125 feet featuring a black extruded aluminum case with red LEDs. The displays are easily hung on the wall. Contact Microframe for more information concerning our ceiling mounts. A 24-volt AC adapter is included which plugs in an AC outlet.

REMOTE CONTROL (RECOMMENDED OPTION)

The wireless remote control allows you to advance the numbers, go back a number, reset the numbers, and set up the programming. Multiple remotes can be used on one or more displays. The remote has a range of between 15 to 30 feet (line of sight).

CLOCK

Microframe offers two Time-of-Day Clocks available in 4 or 6-digits. The 4-Digit displays hours and minutes or minutes and seconds. The 6-Digit displays hours, minutes, and seconds. Although each clock can be set with two buttons on the back of the display, it is strongly recommended that a remote be purchased in all situations where the clock will be reset more than a few times a year.

COUNTDOWN TIMER

The timers can be set to any time and begin counting up or down with the press of a button on the remote control or with the push button wired to the back of the display.

User adjustable settings include, Input button logic, Start and Stop time, Count down/up, auxiliary output time and colon flash rate among others. It is strongly recommended that a remote be purchased to set up all the features of the countdown timer.



Model 5460 Display



Remote Control



Model 5440 Display



Model 5430 Display

PRICING

54202 Display System	\$258
One Model 5420 Display	
One Wireless Remote Control	
Extra Display.....	\$229

54302 Display System	\$308
One Model 5430 Display	
One Wireless Remote Control	
Extra Display.....	\$279

54402 Display System	\$358
One Model 5440 Display	
One Wireless Remote Control	
Extra Display.....	\$329

54602 Display System	\$428
One Model 5460 Display	
One Wireless Remote Control	
Extra Display.....	\$399

