

6300 Series Timer/Counter/Clock

SERIES 6300 TIMER/COUNTER/CLOCK

The 6300 Series display is the most versatile display that Microframe has to offer. Whether you need a special event timer, a countdown clock for a sporting event, a wall clock for your business, an industrial unit counter for manufacturing, New Year's countdown clock, or a production takt timer; Microframe's 6300 Series timer/clock/counter is the high-quality, low-cost solution to meet your needs. The display has large 5.5" tall numbers that are visible up to 125 feet featuring a black extruded aluminum case with red LEDs.

REMOTE CONTROL

The wireless remote control allows you to advance the numbers, go back a number, reset the numbers, and set up the programming. Multiple remotes can be used on one or more displays. The remote has a range of between 15 to 30 feet (line of sight).



Model 6360 Display



Remote Control

COUNTDOWN TIMER

The count up or countdown timers will count days, hours, minutes, seconds, and 100th of seconds. The timer can be set to any time and begin counting up or down with the press of a button on the remote or with the push button wired to the back of the display.

CLOCK

As technology continually improves, so does Microframe's clock display. With improved internal clock components the result is a very accurate time-of-day clock, available in 4 or 6-digit modes. The 4-digit displays hours and minutes or minutes and seconds. The 6-digit displays hours, minutes, and seconds.



Model 6340 Display

COUNTER

Counter mode is commonly used for manufacturing and production piece counting. The display works with most industrial sensors that are used to communicate the number of units/products produced on a production line. This helps improve the efficiency of your plant and resources by providing immediate visual confirmation of manufacturing outputs.



Model 6330 Display

PRICING

6320 Display System	\$248	6340 Display System	\$348
One Model 6320 Display		One Model 6340 Display	
One Wireless Remote Control		One Wireless Remote Control	
Extra Display w/o remote	\$229	Extra Display w/o remote.....	\$329
6330 Display System	\$298	6360 Display System	\$418
One Model 6330 Display		One Model 6360 Display	
One Wireless Remote Control		One Wireless Remote Control	
Extra Display w/o remote	\$279	Extra Display w/o remote	\$399

