

# DigiLink

## FEATURES

- Remote Sensing
- Nurse Call Systems
- Security or Fire Panels
- Building Access Control
- Emergency Call Systems
- Automated Plant Monitoring



## BENEFITS

- Ideal for battery operation
- 500 mW UHF transmitter + encoder
- Multiple, random repeat transmissions
- External aerials can increase range up to 5 miles
- 5 or 10 zones, power monitor and test call facility
- 1 amp open collector output for local siren or switching
- Power consumption is less than 300 microamperes in standby
- Zones can be configured for "normally open" or "normally closed"
- Zones can take wet or dry contacts: 5-15 VDC

## SCOPE DIGILINK

The Scope DigiLink System is a powerful on-premise alphanumeric and/or numeric paging system ideal for security and remote sensing applications. This on-premise system is a reliable, 457.575 MHz paging system (1/4- to 1/2-mile range). This 500 mW UHF transmitter plus encoder has a DC input with an AC adapter. With power consumption under 300 microamperes in standby mode, the DigiLink is ideal for battery operation.

## HOW IT WORKS

This system is available in two versions: 5- and 10-zone. Each zone can be set to accept dry contact closures or voltage input of up to 15 volts DC. You can mix inputs on units to meet any requirement. The units are usb programmable using an optional programming interface. The 5-Zone DigiLink can send 5 different messages for 5 different alarm conditions, and the 10-Zone DigiLink can send 10 different messages for 10 different alarm conditions.

## APPLICATION

When the contact closure senses an activity, it sends a pre-programmed message to a pre-defined pager or group of pagers. For example, Zone 1 may connect to the back door and when it is opened or a doorbell button is pressed, it alerts the manager for a delivery. Zone 2 may connect to a freezer to alert the manager when it reaches zero degrees. Zone 3 may connect to a button on the customer service counter to page a clerk when a customer comes in for help.

## POCKET PAGER

- Icon indicators
- Unread message indicator
- Includes belt clip and holster
- Vibrate/tone or vibrate only
- Bright single-line LCD display
- Uses 1 AAA battery (included)
- Efficient memory management
- Selectable "all message" erase
- 4-Address identification code (ID)
- 12-character liquid crystal display
- Message capacity: 240 characters
- Scrolling for messages up to 12-digits



## SCOPE GEO 40

- Icon indicators
- Message time stamp
- 65-message memory
- Unread message indicator
- Bright two-line LCD display
- Vibrate/tone or vibrate only
- Includes belt clip and holster
- Uses 1 AAA battery (included)
- Efficient memory management
- Selectable "all message" erase
- 4-Address identification code (ID)
- 20-character liquid crystal display + scrolling
- Message capacity: 10,000 characters, 65 messages

## PRICING

DigiLink 5-Zone 12v DC (B3057) . . . . .	\$384
DigiLink 10-Zone 12v DC (B3058) . . . . .	\$459
Scope GEO40 Alphanumeric Pager . . . . .	\$109
Scope Pocket Pager . . . . .	\$39

